

Manhattan

T2·R

 FreeviewHD
RECORDER



GET STARTED



For assistance,
call us on 020 8450 0005
or visit manhattan-tv.com/help



Check Freeview HD
coverage in your area by
visiting freeview.co.uk

INSTALLING YOUR T2•R

Unpack the following from your Giftbox:




Remote control




Manhattan T2•R



2x AAA batteries



HDMI cable



Power adapter

You'll need:

- A TV with an HDMI input
- A coaxial TV aerial cable



Before you plug in, please read the Safety section of the Important Information booklet.

Connect Up


- Connect the coaxial TV aerial cable from your aerial wall socket to your T2•R.
- Next, connect the T2•R to your TV using the HDMI cable provided.
- If you want to view Freeview's free and premium streaming channels and receive software updates over the internet, connect the T2•R to your internet router using an Ethernet cable.
- Finally, plug the AC power adapter into a wall socket that is turned off, then connect the other end to the T2•R.

💡 If you want to use your TV's tuner, connect the Loop Out connector to the Aerial input of your TV.

💡 If your TV doesn't have an HDMI input, the T2•R has an analogue AV output that you should be able to connect to your TV using the Manhattan AV Kit (not included). See the included leaflet or contact us for more details.




Switch On

- Open the battery compartment cover on the back of the remote by sliding the cover. Insert the batteries, matching the + and – symbols to what is marked on the inside of the compartment. Replace the cover.
- Turn on the wall socket you connected the Manhattan T2•R to and it will switch on.
- Turn on your TV set and choose the HDMI input you connected your Manhattan T2•R to. Most TV remotes use a button labelled 'AV', 'SOURCE', 'INPUT' or , with each press cycling through the TV's inputs.

💡 Your Manhattan remote can be easily programmed to control your TV's input, adjust its volume and turn it on and off. See page 13 for details.

Follow the on-screen instructions to set up your T2•R. It takes about 5 minutes, which is the perfect amount of time to read the rest of this Guide!

WATCHING TV



The Channel Browser

While watching TV, press **OK** on your remote control to display the Channel Browser, then use the directional pad to browse what's on.

- When a programme on now is highlighted, press **OK** to change channel and watch it. If the programme is on later, pressing **OK** sets a reminder.
- To set a recording, press **Ⓡ**. If the programme is part of a series, you can choose to record the entire series or just the episode.
- To view detailed info about a highlighted programme, press **INFO**.

Quickly Changing Channel



There are 3 ways to directly change channel while watching TV:

- Press **P-UP** or **P-DOWN** to change to the channel above or below.
- Enter a channel number with the number buttons.
- Press **SWAP** to change to the last channel you were watching.


Entering Live Pause

Press **PAUSE** to enter Live Pause. You can also rewind or skip back (see page 6).

Volume & Accessibility

- Turn the volume up or down with **+**  **-**. Mute and unmute the sound with .
- Toggle Subtitles and Audio Description on and off with the **SUB** and **AD** buttons.

TV GUIDE



Press **GUIDE** to display the full TV Guide and see what's on across the next 7 days. As with the Channel Browser (see opposite page), use the directional pad to browse what's on, **OK** to watch programmes or add reminders, **R** to set recordings and **INFO** to view detailed programme info.

Record Icons

- R** Scheduled or in-progress recording
- R** Recorded programme
- R** Scheduled or in-progress series recording
- R** Recorded episode that is part of a series recording

Quickly Navigating

As there are lots of channels and programmes to browse, you can get around more quickly by:


- Entering a channel number with the number buttons
- Pressing **P-UP** or **P-DOWN** to page up or down
- Holding **LEFT** or **RIGHT** to skip through time
- Pressing **◀** or **▶** to skip 24 hours backwards or forwards

When you've browsed ahead, press **◀** to skip back to what's on now.

Lists

The TV Guide can be filtered to show only HD, Radio or your Favourite Channels. Press **■** to select a list. You can also choose to edit your Favourites.

LIVE PAUSE



The T2•R is always recording the channel you're watching and will store ('buffer') up to the last 2 hours. When you change channel, what had previously been recorded is cleared and recording starts again. There are many ways to take advantage of Live Pause:


- Press **PAUSE** when you need to get the door, make a cup of tea, etc.
- Press **LEFT** to instantly skip back 10 seconds; helpful if you've missed some dialogue or want to replay a great moment.
- Press **◀◀** to seek backwards to a specific point. Each press of **◀◀** increases the seek speed. Press **▶▶** to start playback again.

Depending on how long you've been watching a channel, there can be more than one programme in the buffer. The playback bar always shows the current programme and channel being viewed. As you rewind back past the start of a programme, the playback bar will update to show the previous programme. To move forward:


- Press **▶▶** to seek forwards. Each press of **▶▶** increases the seek speed. Press **▶▶** to start playback again.
- Press **RIGHT** to skip forwards 30 seconds

To return to live TV, press **STOP** or **EXIT**.

When watching a programme and you press **Ⓜ**, anything that's in the Live Pause buffer will be saved along with the rest of the programme.

 The skip forward and backward durations can be changed in the Recording & Playback section of Settings.

RECORDINGS



Press **RECORDINGS** to display a list of all your recordings. Use **UP/DOWN** to browse the list and **LEFT/RIGHT** to select a section:

- **SCHEDULE** – Your planned recordings and reminders
- **SERIES** – Recordings that are part of a series
- **MOVIES** – Movies that have been recorded
- **KEPT** – Recordings you have chosen to keep
- **TRASH** – Recordings you have deleted but can still be recovered

To play a recording or open a series folder, press **OK**. To keep or delete a recording, press **R** and select the option. Deleted recordings are sent to the Trash and permanently removed after 30 days. If you run out of space, the T2•R will make space for new recordings by removing recordings from the Trash followed by the oldest recordings that have not been kept.


In the list, the ● icon before a recording indicates it is unwatched and the ○ icon that it is partially watched. When a partially watched recording is highlighted, a blue bar indicates how much of it has been viewed so far.

All upcoming recordings and reminders are displayed in the **SCHEDULE**. To edit a scheduled recording, press **R** and select an option. To set or cancel a reminder, press **OK**.

Playback








- Press **◀** or **▶** to seek backwards or forwards to a specific point. Each press increases or decreases the seek speed. Press **PLAY** to resume playback.
- Press **LEFT** to skip back 10 seconds or **RIGHT** to skip forward 30 seconds.
- Hold **LEFT** or **RIGHT** to skip in 10% jumps.
- Press **■** to display the Go To menu. Enter a specific time to go to with the number buttons or press **■** again to restart playback.
- Press **STOP** or **EXIT** to end playback and return to the Recordings Menu.


PROGRAMME INFO



The info screen displays the description, genre and other key information for a programme. It is displayed by pressing **INFO** when watching TV, using the Channel Browser, the TV Guide or the Recordings Menu.

Icons


-  Part of a series
-  In HD
-  Surround sound audio
-  Programme is in two or more parts (e.g. a movie split by the evening news).
-  Subtitles
-  Audio Description
-  Guidance

 For a full overview of all the icons on your T2•R go to: Settings → Help → Guide to Icons

Browsing Series & Repeats

- If the programme is part of a series, you can press **UP** to browse all episodes in the schedule.
- If the programme is showing again on any channel, you can press **DOWN** to browse repeats in the schedule.

MENUS



Press **MENU** to display the Main Menu. Use **UP** or **DOWN** to highlight an option and **OK** to select it.

Press **BACK** to go back to a previous menu or **EXIT** to return to full screen TV.

Main Menu Options

TV Guide

View what's on across the next 7 days. You can also press **GUIDE** (see page 5).

Recordings

View and manage your recordings.

Channels

Manage your favourite and protected channel lists or delete channels (see page 10).


Settings

View and modify the T2•R's settings.

Help

View help about using your T2•R and detailed System Information for troubleshooting such as software version and signal information.

CHANNELS



Favourite Channels

Select 'Edit Favourites' in the Channels Menu to choose channels for your favourites list. As explained on page 5, your favourites can be used to filter the TV Guide. They can also be quickly browsed using the Now & Next Browser:

- While Watching TV, press **OK** to display the Channel Browser. Notice that in the top left of the browser it shows: **FAVOURITES**
- While the Browser is displayed each press of **OK** cycles through your favourite channels

Protected Channels

Protected Channels are hidden and can only be shown by entering your PIN. To choose channels to protect, select 'Edit Protected Channels' in the Protected Channels Menu and then enter your PIN.

When you want to temporarily show your protected channels, select 'Show Protected Channels' in the Protected Channels Menu. After entering your PIN, all Protected Channels will be shown until the T2•R next enters standby or you choose the option to hide them again.

Deleting Channels

Channels can be deleted entirely by selecting the 'Delete Channels' option in the Channels Menu. If you want to restore them in the future, select the 'Smart Retune' option in the Tuning section of Settings.

SETTINGS

View and change your T2•R's settings by pressing **MENU** and selecting 'Settings'. Please be aware of the following Settings that can cause your T2•R to turn on or off automatically:

Reminder AutoTune

Reminders are displayed just before a programme is scheduled to start. The T2•R has an option in the Tuning section of Settings called 'Reminder AutoTune' that is turned off by default, meaning:

- A reminder will only be displayed if the T2•R is on
- You must choose to watch the programme before the reminder times out to change the channel
- If you don't, the reminder will be cancelled and the channel will not change

When 'Reminder AutoTune' is turned on:

- If the T2•R is in standby it will turn on for the reminder and the channel will change automatically
- If the T2•R is turned on the reminder will be displayed as normal and at the end of the 30 seconds the channel will change automatically

Auto Standby


The T2•R will go into standby automatically if no buttons are pressed for 3 hours. The length of Auto Standby can be changed or it can be disabled altogether in the System section of Settings.

ENERGY SAVING

To meet EU energy consumption requirements, the T2•R is initially set up so that:

- The Loop Out socket on the rear of the T2•R is unpowered in standby. If you connect an aerial cable from the socket to your TV's aerial input and want it to work when the T2•R is in standby, turn on 'Loop Out in Standby' in the System section of Settings. Please note that power consumption will be increased.
- Auto Standby is enabled (see above).

YOUR REMOTE




Change Blink Mode

By default, the LED on the T2•R remote blinks when a button is pressed. Toggle this off or on by holding the **SUB** and '1' buttons for 3 seconds until the LED blinks.

CONTROL YOUR TV

Your T2•R remote can be programmed to control the following functions on your TV:


- Standby
- AV (input selection). On most TV remotes this is labelled 'AV', 'SOURCE', 'INPUT' or .
- Volume Up/Down
- Mute


IMPORTANT

- **Please turn the volume up on your T2•R to maximum before you continue.** If you do not, the volume from your T2•R will always be lower than it should be.
- Some TV's use non-standard remote signals and may not be supported.

Program your Manhattan Remote


To start, lay the T2•R and TV remotes flat on a table facing each other 2cm apart.



1. Press the bottom left (SUB) and right (AD) buttons on the T2•R remote for 3 seconds.
 - » The **Standby** button on the T2•R remote lights up blue.
2. Press the button on the T2•R remote you want to program: **Volume Up**, **Volume Down**, **Mute**, **AV** or **TV** .
- » The **Standby** button on the T2•R remote starts blinking.
3. Press and hold the matching button on the TV remote.
 - » If the button is programmed, the light from the **Standby** button on the T2•R remote turns off and then goes solid again after about a second.
 - » If the button fails to be programmed, the light from the **Standby** button flashes on and off 4 times to indicate an error and you are returned to the start of Step 2.
4. Repeat steps 2 and 3 for all the buttons to program.
5. Press **OK** on the T2•R remote to leave programming mode.
 - » The light from the T2•R remote's standby button turns off.


Test each of the buttons with your TV. If one doesn't work, repeat the steps to program it.

Reset Your Remote

To clear all programmed buttons and return them to their original state, hold the **SUB** and  buttons for 3 seconds until the LED blinks.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	WHAT TO DO
There's no picture or sound and the T2•R's menus can't be seen	The HDMI/AV cable may be disconnected.	Check the HDMI or AV cable connections between the T2•R and your TV.
	The input the Manhattan T2•R is connected to may not be selected on your TV.	Select the correct HDMI/AV input (see your TV's manual for guidance).
	Your TV may not correctly communicate the resolutions it is capable of and an incompatible resolution may be selected.	<ul style="list-style-type: none"> • Turn the T2•R on and wait 30 seconds • Press MENU • Press & hold '0' for 5 seconds • The T2•R will try each resolution for 15 seconds: 1080p then 1080i then 720p • Select 'Confirm' when you see a picture
The picture and sound keep breaking up or 'No signal' is displayed on screen	Weak signal from your aerial.	Check your signal in 'Help' → 'System Information'. If it's weak or not present, get a professional to check your installation – your aerial may provide a better signal if it is realigned or moved somewhere else. We don't recommend using an indoor aerial. As a last resort, try using a signal amplifier or booster to improve reception.
	Some TV aerials installed with a signal amplifier need a power supply from the receiver because they do not have their own.	If you have connected a signal amplifier, you can have the T2•R supply it with a +5V DC supply by selecting the option in the System section of Settings.
Channels not working after moving home	The new home is in a different Freeview transmission area.	Select 'Full Retune' in: Settings → Tuning → Retune
You do not hear any sound on HD channels	Your TV does not support Dolby Digital audio.	Select 'Stereo PCM' in: Settings → Picture & Sound → Audio Output.
The TV picture is not HD	You may be watching an SD channel or you are using the AV connection to your TV.	Connect the T2•R with an HDMI cable to an HD-Ready TV and select an HD channel.

PROBLEM	POSSIBLE CAUSE	WHAT TO DO
Your remote control does not work	The T2•R is not turned on or its front is obstructed.	Ensure the front of the receiver is not obstructed.
	Batteries are weak in the remote control.	Replace batteries in the remote control.
Your T2•R switches off after 3 hours	The T2•R is set to go to standby by default after 3 hours without interaction.	Turn 'Auto Standby' off or select a different duration in: Settings → System.
You can't remember your PIN	You've forgotten it or someone has changed it.	Your PIN can be reset with the master PIN. Please contact us.
You empty the trash but available space does not increase	Available space already includes anything that is in the trash	N/A
You programmed your Manhattan remote to control your TV but the volume seems low	You did not set the T2-R's volume to max before programming your Manhattan remote to control your TV.	<ul style="list-style-type: none"> • Reset your Manhattan remote by holding the SUB and  buttons for 3 seconds until the LED blinks • Turn the volume up to max on your T2-R • Reprogram your Manhattan remote to control your TV (see p13)
The volume & mute buttons on your T2•R remote do nothing	They have been programmed to control the volume of another device (see p13).	Reset your T2•R remote by following the instructions in 'Reset Your Remote' on p13.
Loop Out does not work in Standby	The "Loop Out in Standby" setting is not turned on	Turn on 'Loop Out in Standby' in: Settings → System.
You can't connect your T2•R to the internet to update its software	It's not possible to connect your T2•R to an internet router with an Ethernet cable	Software updates can be downloaded from our website and installed using a USB stick. When registering your T2•R you can choose to be notified by email when updates are released. Please contact us if you need help.

Manhattan



The details in this guide are correct at the time of going to print and are for guidance only. Product features outlined are subject to change at any time without notice. © 2021 Manhattan TV Limited. Manhattan is a registered trademark of Manhattan TV Limited; registered company no. 2247629. The FREEVIEW words and logos are trade marks of DTV Services LTD. © DTV Services Ltd. v9 (03/06/21)