

Manhattan

Manhattan SX v1.07 Release Notes (11/11/19)

Improved

- Channel lists are now persistent: After selecting a list in the TV Guide (e.g. Favourites or HD Channels), as long as the channel being viewed is on that list when you re-enter the TV Guide, the list will continue to be selected. Changing to a channel not on the list or pressing Standby will reset the list back to All Channels.
- Wi-Fi can be disabled before any Wi-Fi network has been configured.
- When Wi-Fi is disabled the antennas are now totally disabled and no radiation can be detected from the SX.

Fixed

- The TV Guide would unnecessarily scroll ahead 30 mins on every hour and half hour, even if 'now' was not in view.
- The system could freeze during boot-up while fetching the information for the Guide.
- Deleted regional services could be added again unexpectedly after a retune.
- No audio would be heard using the Sony HT-SF150 Soundbar on HD channels when the Audio Output was set to 'Surround'.
- Sony Crime and Sony Crime+ could not be tuned as manual channels.
- The Now and Next information would not show for Channel 4 HD when tuned as a manual channel.