

Manhattan

Manhattan T3•R v1.07 Release Notes (09/06/20)

Improved

- SD picture quality
- The T3•R will ignore retune events for transmitters that it cannot receive or are not currently tuned.
- The latest networking libraries have been integrated for improved network performance and reliability (e.g. in a Carrier Grade NAT environment).
- When playing a recording or in live pause, subtitles could take up to 30s to show after turning on
- The T3•R will wait for the Hard Drive to be unmounted before restarting, going to sleep or standby.

Resolved

- After viewing Programme Info using the INFO button, the TV Guide could become less responsive until the next restart.
- Audio Description could become out of sync and the volume of the main audio could dip unexpectedly.
- The incorrect regional channels could be chosen when the T3•R receives signals from multiple regions.
- When using surround sound speakers audio and the T3•R was set to output surround sound, audio could be heard for HD programmes with 2.0 audio from only the left and right speakers. *HD programmes are broadcast with either AAC 2.0 or 5.1, both of which the T3-R transcodes to Dolby Digital. For more info, please see the BBC's blog post [here](#).*
- Playback of a recording could unexpectedly exit to live TV following a dynamic change in the broadcast of a programme being recorded.
- Freeview Play apps (BBC iPlayer, ITV Hub, etc) could sometimes not be listed on the Home Screen.
- When playing on demand content that was launched directly from a Manhattan menu (e.g. Featured or Search), the T3•R could crash after pressing BACK.
- A blank screen could be shown at the end of playback in ITV Hub (the system still responded to BACK to return to the ITV Hub menu or EXIT to return to the Manhattan menu).

- When using an ITV Hub+ account, playback of videos could fail
- Programmes on ITV channels with Audio Description would not show the AD icon.
- The video could freeze during playback of a recording or in live pause.
- After watching a recording of a live programme (chase playback) to the end, when next using live pause, it could freeze and then fail to respond until a restart.
- Playback of a recording could stop immediately after starting.
- Deleted programmes that had been emptied from the Trash could be shown as recorded in the Guide and Channel Banner meaning that they could not be re-recorded.
- When pressing ® for the Record Options of a programme on now in the Channel Banner, the incorrect options would be shown.